



madebyzen

SOTO AROMA DIFFUSER



TABLE OF CONTENTS:

A. Function

B. Specification

C. Operation Procedure

D. Maintenance

E. Troubleshooting

Congratulations on your purchase of the Ultrasonic Aroma Diffuser. Please keep this manual for further reference and maintenance.



FUNCTION

Create a peaceful and calming heaven anywhere with the SOTO. Elegant and aesthetically pleasing, the SOTO delights your senses and adds luxe to everyday living.

The SOTO has colour changing mood lighting, which easily moves through a rainbow of colours or can be set on one single colour of choice. It also has a no light option to continue soothing whilst you sleep.

The SOTO Aroma Diffuser also acts as a mini-Humidifier - creates a cool, scented and relaxing mist which will spread fragrance quickly and effectively.

By adopting aromatherapy principles, your body will be gradually relaxed, and your skin will be moisturised at the same time.



SPECIFICATION

Product Size: approx. 180x107mm

Voltage: DC 24V

Power: 12W

Water Capacity: 80ml

01. Vent hole

02. Ceramic disc

03. Water tank

04. Diffusion cone

05. Max. Water level line


06. Water discharge indicator

07. Mist outlet

08. Button

09. DC Jack

10. Switching adaptor





OPERATION PROCEDURE

IMPORTANT NOTES BEFORE USE:

Place the Aroma Diffuser on a dry, even surface.

DO NOT use detergents, solvents or abrasive agents to clean the Aroma Diffuser.

Use only clean water at room temperature to fill the water tank.

Disconnect the power of Aroma Diffuser before performing machine maintenance and cleaning.

Corrosive oils such as Citrus, Citronella and Lemon should be avoided as they can cause permanent damage to the unit.



1. Remove the diffusion cone.



2. Fill the water tank with clean tap water (max. 80ml)



3. Add 3-5 drops of your favourite essential oil into the water.



4. Replace the diffusion cone




5. Plug the adaptor and press the **ⓐ** button.

NOTE: Do not tilt or move the Aroma Diffuser or attempt to empty or refill it while it is operating.



Use of selection switch:



MAINTENANCE



1. Press the **D** button to turn off the unit and unplug the adaptor



2. Remove the diffusion cone



3. Empty water following the water discharge indicator




**WARNING: DO NOT
EMPTY WATER FROM
THE VENT HOLE**

4. Use a damp cloth to clean the exterior of the housing.
Use a clean swab or cloth to clean the water tank.



NOTE: we advise you to empty and rinse the water tank and wipe it dry with a clean cloth every time you use a different type of essential oil.

TROUBLESHOOTING

SYMPTOM	POSSIBLE CAUSE	SOLUTION
NO MIST	Power supply is not connected	Plug the power in and press the  button
	Insufficient water	Refill water until water is sufficient
	Too much water (exceeded 80ml)	Pour away excess water
	Mist outlet is blocked by water film or sundries	Keep the mist outlet clean
	The ceramic disc is aging after running for approximately 3000 hours	Please contact your local dealer



WARNING



In case of abnormal situations such as smoke, peculiar smells and cacophony, any further use may result in an accident such as fire or electric shock. You should unplug the adapter immediately and contact your local dealer.

Never wrap the adaptor with cloth or paper, or it could not dissipate the heat properly, which may cause it to melt or cause a fire.

Never attempt to disassemble or repair the product. In case of internal inspection or repair needed, please contact your local dealer.

Please keep the product out of reach of children to avoid and injury or electric shock.

The Aroma Diffuser is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.